
INSTRUCTION MANUAL

3arm®

SERIES 4



TECNOSPIRO MACHINE TOOL, S.L.U.

P.I Pla dels Vinyats I, s/n nau 1

08250 - Sant Joan de Vilatorrada. Barcelona - España

Telf. +34 938 76 43 59

E-mail: 3arm@3arm.net



TECNOSPIRO
MACHINE TOOL SLU



www.3arm.net

TABLE OF CONTENTS

1	INTRODUCTION.....	4
2	ABOUT THIS MANUAL	5
2.1	CONSIDERATIONS.....	5
2.2	DOCUMENT VERSION	6
3	SAFETY INFORMATION.....	6
3.1	SCOPE OF APPLICATION.....	6
3.2	ALERTS AND GENERAL CONSIDERATIONS.....	6
3.3	EXCLUSIONS.....	8
3.4	SYSTEM INTEGRATOR.....	8
3.5	SYMBOLS AND ICONS	9
3.6	PERSONAL PROTECTION EQUIPMENT (PPE)	9
3.7	TRAINING LEVEL OF THE STAFF INVOLVED.....	9
4	GENERAL DESCRIPTION AND TECHNICAL INFORMATION	10
4.1	MAIN PARTS.....	10
4.2	CONFIGURATIONS.....	11
4.3	DIMENSIONS.....	12
4.4	MOVEMENTS	14
4.5	REACTION TORQUE	15
4.6	TECHNICAL SPECIFICATIONS.....	16
4.7	IDENTIFICATION	16
5	INSTALLATION	17
5.1	INSTALLING AND CHANGING TOOLS.....	19
6	ADJUSTMENTS.....	20
6.1	BALANCING THE ARM.....	20
6.2	BALANCED, CENTRED POSITION.....	21
6.3	REGULATION OF THE RESISTANCE TO ROTATION.....	22
6.4	HOW TO SECURE TOOLS WITH A SQUARE SECTION	23
7	OPERATION	24
7.1	L11 MANUAL LOCK	24
7.2	L22 PNEUMATIC LOCK	25
7.3	L92 PNEUMATIC LOCK	28
7.4	LIFTER / PNEUMATIC COLUMN.....	35
8	MAINTENANCE.....	37
8.1	COMPRESSED AIR MAINTENANCE UNIT.....	37
8.2	PNEUMATIC LOCKING BRAKES.....	37

8.3	TIGHTENING THE SCREWS	37
8.4	GENERAL CLEANING	37
8.5	REPLACING THE GAS SPRING AND CYLINDER.....	38
8.6	ADJUSTING THE SPRING REGULATION SYSTEM.....	39
8.7	REPLACING THE HEAD	40
8.8	REPLACING RADIAL PADS L11	41
8.9	REPLACING TILTING PADS L11	42
8.10	MAINTENANCE TABLE	43
9	PNEUMATIC LOCKS.....	44
9.1	PNEUMATIC LOCKS: IDENTIFICATION.....	44
9.2	CHECK CONNECTIONS: DEVICE CONTROL – 3arm®.....	44
9.3	CHECKING THE AIR SUPPLY	45
9.4	CHECK CYLINDER ADJUSTMENT.....	46
9.5	REPLACING THE CYLINDER AND/OR RADIAL PADS	47
9.6	REPLACING THE CYLINDER AND/OR SWIVEL PADS.....	49
10	SPARE PARTS.....	50
11	ACCESSORIES	56
11.1	COMPATIBILITY OF ACCESSORIES.....	60
12	WARRANTY.....	60
13	GUIDELINES FOR PACKAGING, TRANSPORT AND DISMANTLING	61
13.1	PACKAGING	61
13.2	TRANSPORT.....	61
13.3	DISASSEMBLY.....	61
	CE STATEMENT OF COMPLIANCE	63

1 INTRODUCTION

Dear Customer,

We would like to congratulate you on your choice and we are pleased to continue our constant work to provide our customers with a simple, reliable and versatile way to improve ergonomics in the workplace.

We hope these simple instructions will help you commission and operate the arm you have selected. We suggest you pay special attention to the pages on the concepts of installation, maintenance and safety.

We hope your arm will have a long life and that you can reaffirm the very good investment you have made in acquiring a 3arm ©.

2 ABOUT THIS MANUAL

This document corresponds to the Series 4 instruction manual.

- ORIGINAL MANUAL -

Intellectual/Industrial Property Information:

Tecnospiro Machine Tool, S.L.U. (the Company) informs that all content in this document including, for example, the text, images, graphic designs, brands, trading and company names (hereinafter, the Intellectual/Industrial Property), belong to the Company and that the Company is the exclusive owner of their use. Copying, reproduction, distribution, public communication and total or partial use of the Intellectual/Industrial Property, in any form or manner, even quoting the sources, is prohibited, unless expressly agreed in writing by the Company. The use of any content that due to its characteristics is similar to the Industrial/Intellectual Property is also considered an infringement of the Company's Industrial/Intellectual Property rights.

2.1 CONSIDERATIONS

- ✓ Before using the equipment, be sure to read this instruction manual and follow the instructions for use and safety correctly.
- ✓ All the instructions listed in this manual refer to the individual unit. It is the end user's responsibility to analyse and apply all the necessary safety measures required for the end use.
- ✓ This manual must be kept for the entire life of the equipment, in a place close to it for future consultations.

- ✓ If any part of this manual is unclear, confusing or inaccurate, please do not hesitate to contact us.
- ✓ The content of this manual may be subject to change without prior notice.
- ✓ If the manual is lost or damaged, contact TECNOSPIRO MACHINE TOOL, S.L.U. for a replacement.
- ✓ Reproducing or sharing this documentation – or part of it – to third parties is only permitted with express written authorisation from TECNOSPIRO MACHINE TOOL, S.L.U.
- ✓ The illustrations shown in this manual may differ in some details with respect to their specific configuration and should be understood as a standard representation.

Paragraphs indicating assembly, adjustment, installation or maintenance steps are framed with a brown background.

Paragraphs with highlighted information are framed with a grey background.

2.2 DOCUMENT VERSION

Document	Date - version
Instruction manual Series 4	31/10/2023

3 SAFETY INFORMATION

3.1 SCOPE OF APPLICATION

This chapter contains very important information related to the safety of your arm; it is aimed at all staff involved in any of the stages of the life of this equipment (transport, assembly, installation, commissioning, adjustment, learning, operation, cleaning, maintenance, troubleshooting, dismantling/removal from service).

3.2 ALERTS AND GENERAL CONSIDERATIONS

- ✓ The equipment described in this document has been built in accordance with the current technological level and in accordance with the applicable technical standards in terms of safety. However, improper use, or incorrect integration by the end user can generate risk of injury.
- ✓ The equipment should only be used in perfect technical condition, respecting the safety regulations and taking this document into consideration.
- ✓ Any breakdown that may affect safety should be corrected immediately.
- ✓ Without the proper authorisation of TECNOSPIRO MACHINE TOOL, S.L.U.

No modification of equipment should be made.

- ✓ The equipment must only be operated for its intended use. Any other use is strictly prohibited. Any use other than that indicated is considered misuse and is prohibited. The manufacturer assumes no responsibility for any damage that may arise from it. This is solely at the user's own risk.
- ✓ It is the responsibility of the integrator, owner and/or end user to determine the suitability of the product for each use, as well as its place of installation and the specific definition of the task to be carried out with this product within the limits stated in this manual.
- ✓ Do not use the equipment in any way that is not considered in this manual and pay special attention to the uses mentioned in section 3.3 EXCLUSIONS, which must not be carried out.
- ✓ The operator must only use the equipment after having received the instructions for its use.
- ✓ The integrator/end user must ensure that the gripping device is suitable for the end application.
- ✓ Do not exceed the maximum working loads indicated in this manual and in the identification on the structure of the equipment.
- ✓ It is recommended that only one operator use the equipment at a time, any other use must be evaluated by the integrator/end user.

- ✓ When it is not in use, it must be left in the retracted or parking position. Ensure the air supply to the equipment has been cut off at the end of the working day.
- ✓ The operator may only use the equipment for safe movements, accompanying the movement of the equipment at all times, and thus reducing the risk of uncontrolled or involuntary movements.
- ✓ Although the parts with a higher risk of possible shearing or mechanical gripping are protected and have guards, it is forbidden to manipulate the moving components and joints when it is in use.
- ✓ The operator must remain outside of the vertical path of the swivel arm.
- ✓ The work area of the equipment and its surrounding area must respect conditions of safety, health and hygiene at work. It is the integrator/end user's responsibility to conduct a study to guarantee safety.
- ✓ The presence of third parties in the work area of the equipment should be restricted as much as possible, thus avoiding any impact on safety. For any other use, an additional study of the hazards derived from this way of working must be carried out.
- ✓ Only authorised personnel may be present in this area while the equipment is in use.
- ✓ It is important that the users who operate this equipment are familiar with and sufficiently trained to use this product or similar products.
- ✓ It is recommended that the operator have basic knowledge of: Safety procedures, precautions and safe working habits.
- ✓ In any case, the operator must read and understand this manual before use regardless of their knowledge, training or experience with similar equipment, especially the sections dedicated to installation, operation and safety.
- ✓ To the perimeter of the equipment, you must add the opportune distance to allow people to walk around it safely. The work areas must be kept clear of obstacles, columns, etc. that could hinder the work of the operators.
- ✓ Before any type of adjustment or maintenance task, the staff and/or operators responsible for these tasks must bear in mind that the 3arm© arm is configured to work with a certain range of loads.
- ✓ Suitable spaces must be available to carry out maintenance, adjustment, cleaning, etc. tasks.
- ✓ If you have questions about handling or maintenance procedures, please contact the authorised technical service.

- ✓ Protective equipment must be used pursuant to the manufacturer's instructions for the tool attached to the arm.
- ✓ If for any manipulation, adjustment or maintenance task, or for any other reason, the load is released from the arm (for example, when changing the tool), the arm may suddenly ascend sharply and could cause harm. Carefully read the section *Safety considerations in maintenance and adjustment tasks* to avoid such accidents.



- ✓ Lifting devices are subject to different regulations in each country. These regulations may not be specified in this manual.

3.3 EXCLUSIONS

The following is beyond the scope of use of this arm:

- ✓ Operation in severe conditions (e.g. extreme environmental conditions such as freezing, high temperatures, corrosive environment, strong magnetic fields).
- ✓ Loads greater than the maximum working load limits (WLL).
- ✓ Use in areas with risk of explosion.
- ✓ Installation in outdoor areas.
- ✓ Handling of any component or functions of the equipment outside of those specified in this manual.
- ✓ Use by people with some type of disability or by animals.

3.4 SYSTEM INTEGRATOR

The system's integrator or end user is responsible for integrating the machine in the installation, respecting all the relevant safety measures.

The integrator/end user is responsible for the following tasks:

- ✓ Siting the equipment.
- ✓ Connecting the equipment.
- ✓ Risk assessment.
- ✓ Facilities with the necessary safety and protection functions.
- ✓ Issue of the EC statement of compliance.
- ✓ Placement of the CE marking.
- ✓ Preparing the machine's service instructions.

3.5 SYMBOLS AND ICONS

Throughout this manual and in the structure of the machine, different symbols and pictograms can be observed, the meaning of which is summarised below.

	<p>General danger symbol. It is usually accompanied by another symbol, or a more detailed description of the danger.</p>
	<p>Trapping hazard</p>

3.6 PERSONAL PROTECTION EQUIPMENT (PPE)

The personal protection equipment for this arm is merely safety footwear for all stages of the life of the equipment.

It is the integrator/end user's responsibility to define the personal protection equipment derived from the final application of the equipment in order to comply with the essential health, safety and hygiene requirements.

Operators must not wear loose clothing, rings or bracelets that may fall within the equipment's mechanism.

It is also mandatory to wear hair tied back to avoid snags with the moving parts of the equipment.

3.7 TRAINING LEVEL OF THE STAFF INVOLVED

All people working with the equipment must have read and understood the safety chapter in the documentation.


The minimum training level required to use the equipment is:

- Production operators: occupational risk prevention course, full training on the workstations and on the residual risks of the equipment. Minimum of one year's experience in similar facilities.
- Maintenance workers: Occupational risk prevention course, full training on the handling, operation, maintainability and conservation of the equipment and residual risks. Minimum of two years' experience in similar facilities and with the technical level necessary to perform tasks without problems.
- Cleaning operators: course on workplace hazard prevention, training on products and procedures for carrying out cleaning tasks.
- Apprentices/students: They may only work on the equipment if supervised at all times by one of the facility's suitably qualified employees.
- Public (non-operators): visitors or passers-by must maintain a minimum safety distance of two metres from the edges of the perimeter of the equipment.

4 GENERAL DESCRIPTION AND TECHNICAL INFORMATION

The equipment consists of two pendulum parallelograms balanced by gas springs. The assembly of both secures the clamping head and keeps it perpendicular to the work area. In addition, locks (manual or pneumatic) can be incorporated that block rotation in the base axis, the joint axes and the tilting movement of the arms.

4.1 MAIN PARTS




- | | |
|------------------|--------------------------------|
| 1.- Base | 8.- Head |
| 2.- Rear cross | 9.- Regulation assembly |
| 3.- Rear arm | 10.- Air filter and connection |
| 4.- Middle cross | 11.- Control panel cover |
| 5.- Joint | 12.- Radial locks |
| 6.- Front cross | 13.- Tilting locks |
| 7.- Front arm | |

i INFORMATION

The equipment in the image is a SN + DM + R4 + L92 arm

4.2 CONFIGURATIONS

4.2.1 CONFIGURATION TABLE



Note: See dimensions of the heads and functional applications in the *Appendix of S0-S3-S4 heads*.

Note: For dangerous environments consider the HARD version with stainless steel handles. (e.g. SN + DS + BA4 + L22H).


Note III: To complement its use with a pneumatic LIFT, switches are included to control it (e.g. SN + DS + BA4 + L22E).

4.2.2 EXAMPLE ORDER

Example order: SN+DM+R4+L92


SN +
 DM +
 R4 +
 L92

4.3 DIMENSIONS



3Arm® Series 4 Bench-top

CONFIGURATION		DIMENSIONS					
Base	Arm	A (mm/in)	B (mm/in)	C (mm/in)	D (mm/in)	E (mm/in)	F (mm/in)
SN	DS (380mm)	610 / 12.2"	510 / 20.1"	1220 / 48.0"	671 / 26.4"	347 / 13.7"	1017 / 40.0"
	DM (500mm)	730 / 28.7"	630 / 24.8"	1460 / 57.5"	832 / 32.7"	506 / 19.9"	1338 / 52.7"




3arm© Series 4 Ceiling

CONFIGURATION		DIMENSIONS					
Base	Arm	<i>A</i> (mm/in)	<i>B</i> (mm/in)	<i>C</i> (mm/in)	<i>D</i> (mm/in)	<i>E</i> (mm/in)	<i>F</i> (mm/in)
ST	DS (380mm)	610 / 12.2"	510 / 20.1"	1220 / 48.0"	366 / 14.4"	652 / 25.7"	1017 / 40.0"
	DM (500mm)	730 / 28.7"	630 / 24.8"	1460 / 57.5"	527 / 20.1"	811 / 31.9"	1338 / 52.7"


4.4 MOVEMENTS

4.4.1 ROTATION MOVEMENTS



- Base rotation movement: 360° (Axis Z₁)
- Joint rotation movement: 180° (Axis Z₂)
- Joint rotation movement: 180° (Axis Z₃)

4.4.2 ASCENDING AND DESCENDING MOVEMENTS




The tilting movement in the ZX plane ranges from -42° to +42° in each arm, obtaining a total vertical stroke of 1017mm (DS) or 1338mm (DM).

4.5 REACTION TORQUE

The maximum torque that can be absorbed by your 3Arm® arm is limited by the type of head used. The following table gives details of the maximum permissible torque for the heads that can be used in conjunction with reaction tools:

HEAD	MAXIMUM TORQUE (Nm)		
	VERTICAL (Vert)	HORIZONTAL (Horiz)	ANGLE (Ang)
A	150 (111 ft lb)	150 (111 ft lb)	X
BA	300 (221 ft lb)	250 (184 ft lb)	X
D/EA/EC/EE	120 (89 ft lb)	120 (89 ft lb)	120 (89 ft lb)
R/RS/RA/RAS/ RB/RBS/RC/SR	300 (221 ft lb)	250 (184 ft lb)	200 (148 ft lb)



For further information, please refer to the annexed manual for heads S0-S3-S4.



TORQUE TOOLS

- ✓ The use of tools with a torque reaction that must be absorbed by the arm requires L22 or L92 configurations. (Pneumatic locks).
- ✓ For L92 configurations, telescopic compensators must also be used [\[See L92 PNEUMATIC LOCK: USE WITH COMPENSATORS page 29\]](#).

4.6 TECHNICAL SPECIFICATIONS

GENERAL TECHNICAL SPECIFICATIONS		
Load capacity ¹		
(Gross load: Tool + head)	Gross load range (DS)	0-21 Kg <i>(46 lbs)</i>
	Gross load range (DM)	0-24 Kg <i>(52 lbs)</i>
Reaction torque ²		
Maximum torque	Vertical work Max.	300 Nm <i>(221 ft lb)</i>
	Horizontal work Max.	250 Nm <i>(184 ft lb)</i>
	Work at any angle Max.	200 Nm <i>(148 ft lb)</i>
Others		
	Resistance to manipulation	0.5 kg <i>(1.1 lb)</i>
Pneumatic specifications ³		
	Power fluid	Pressurised air
	Operating pressure	0.5 to 0.7 MPa <i>(5 to 7 bar)</i>
Operating conditions		
	Temperature	-10°C to + 50°C
	Relative humidity	Max. 70%
	Environment	Industrial environments

4.7 IDENTIFICATION

A sticker on the radial arm identifies the arm and indicates the following features.

CE and UKCA marking, manufacturer (name, address and business name), date of manufacture, serial number, model, maximum working load, maximum working pressure (for versions with pneumatic lock L22 and L92) and voltage (for versions with pneumatic lock L92).



¹The load shown corresponds to the upper limit for a Series 4 arm. This arm may have a lower maximum load. Consult the maximum load of your arm on the identification plate riveted to the structure of the arm.

² The data shown corresponds to the maximum torque that the arm can absorb. These values may be reduced depending on the head used.

³ For versions with pneumatic locks.


5 INSTALLATION




INSTALLATION

- ✓ The work bench or installation location must be a horizontal surface, thus avoiding shifting and deviations.
- ✓ **WARNING!** Do not remove the safety screw before you have finished installing the tool. Otherwise the arm could start a sharp upward movement that could cause harm.

1. Fasten the base of the arm (1) to the work bench with the three M10 screws supplied (Recommended torque 45 Nm) or with the fastening flange (3arm® accessory).
2. Fasten the tool to the head. (See details in *Appendix of S0-S3-S4 heads*).




3. Remove the screw and spacer (2) that stops the tilting arm being in a raised position. Take care as the arm could start a sharp upward movement.
4. Cut the plastic ties (3) that connect the two arms.



5. Air connection (for versions with pneumatic locks L22 or L92 only)

Requires suitable piping tube for use with compressed air. ($\varnothing_{\text{exterior}} = 6 \text{ mm}$ and working pressure 0.5 - 0.7 MPa/ 5 - 7 bar).



6. Wiring connection (for versions L92 only). To connect your 3arm® arm to the controller of your tool [See ELECTROPNEUMATIC SYSTEM p. 34].


5.1 INSTALLING AND CHANGING TOOLS

Before any type of adjustment or maintenance task, the staff and/or operators responsible for these tasks must bear in mind that the 3arm® arm is configured to work with a certain range of loads.



SUDDEN SHARP UPWARD MOVEMENT

If for any manipulation, adjustment or maintenance task, or for any other reason, the load is released from the arm (for example, when changing the tool), the arm may suddenly ascend sharply and could cause harm.



Follow these guidelines to minimise the risks and/or possible damage:

In tool replacement tasks

Take the tilting arm to its highest position and secure it in that position at all times. If necessary, have two operators to carry out this task with total safety.

6 ADJUSTMENTS


6.1 BALANCING THE ARM

Regulate the tension of internal shock absorber if the arm drops or has a lot of upward force.


- 1- Maintain the tilting arm in an approximately horizontal position to facilitate the task.
- 2- Using the flywheel installed for this purpose, in the upper part of the cross, rotate it as necessary.

- Anti-clockwise rotation: Increases the tension in the shock absorber.
- Clockwise rotation: Reduces the tension in the shock absorber.

Bench-top arm



Ceiling arm



6.2 BALANCED, CENTRED POSITION

- Balanced arm position: Tends to stay in the position in which it has been left.
- Centred arm position: Tends to stay horizontal once left free.


It is possible to adjust the arm to achieve balanced or centred adjustment.

A - BALANCED (see image below)

- 1- Turn the Allen screw (*4 mm Allen key*) until the flat part of the screw head is in contact with the eccentric.
- 2- Position the eccentric so the line marking is just under the screw (*5 mm Allen key*).
- 3- Turn the screw back to the original position (Safety lock).

B - CENTRED (See image below)


- 1- Turn the Allen screw (*4 mm Allen key*) until the flat part of the screw head is in contact with the eccentric.
- 2- Position the eccentric so the dot marking is just under the screw (*5 mm Allen key*).
- 3- Turn the screw back to the original position (Safety lock).



6.3 REGULATION OF THE RESISTANCE TO ROTATION.

A stud located at the base of the arm allows the rotation resistance of the arm's axis of movement to be adjusted. The studs can be tightened or loosened with a Nylon tip to regulate this turning resistance (5 mm Allen key).

Regulating the turning resistance is especially useful in situations where the base of the arm is not completely horizontal.



SHIFTING AND DEVIATIONS


Correctly adjusting the regulation of the turning resistance prevents the risk of shifting and deviations during the operation of the arm.

6.4 HOW TO SECURE TOOLS WITH A SQUARE SECTION

To secure the tool correctly, Tecnospiro recommends using ball-tip headless Allen studs for thrust pads. This component allows you to adjust the tool from all sides, adapting the pads to the surface of the tool.



Example of securing a square tool:




Check that the assembly for securing square tools is in the machine packaging.



7 OPERATION

7.1 L11 MANUAL LOCK

The L11 configuration allows manual locking of different arm movements by means of adjustable handles.



- 1- Rear cross radial lock
- 2- Middle cross radial lock
- 3- Front cross radial lock
- 4- Rear arm tilting lock
- 5- Front arm tilting lock
- 6- Head lock⁴

To lock the movement, turn the handle (1, 2, 3, 4, 5 or 6) clockwise.

To unlock the movement, turn the handle (1, 2, 3, 4, 5 or 6) anticlockwise.

Handles	Control movement
1, 2, 3, 6	Radial movement (X-Y plane)
4, 5	Tilting movement (ZX plane)




CAUTION

If the locking handles are not tightened firmly, they will not lock the equipment properly, acting as a friction brake and causing premature wear of the pads.

⁴ Optional, depending on the head. See *Appendix of S0-S3-S4 heads*

7.2 L22 PNEUMATIC LOCK

The L22 configuration allows you to pneumatically lock different arm movements using switches.




- 1- Rear cross radial lock
- 2- Middle cross radial lock
- 3- Front cross radial lock
- 4- Rear arm tilting lock
- 5- Front arm tilting lock

Position of the switches to obtain one lock or another.


Movements	Selectors	Cylinder control
Radial movement (X-Y plane)	 	1, 2, 3
Tilting movement (ZX plane)	 	4, 5

7.2.1 Pneumatic diagram L22



7.2.2 Pneumatic diagram L02/L52

REF	QUANT	CODE	DESCRIPTION
0.1	1	NH029026	AIR FILTER AC10-Q2U003
0.2	1	NH026186	CHECK VALVE AKH04-00
4.0-5.0	1	MV406004	TILTING ARM LOCK CYLINDER
4.1	1	NH121136	MICRO VALVE VM1000-4NU-08



DESCRIPTION			CODE
PNEUMATIC SCHEME S0/S3/S4/S6 - L02/L52			PNEUS30005
* Standardization of the scheme for S0/S3/S4/S6			
	NAME	DATE	REVISION
DRAWN BY	D. Gil	18/05/2022	1
APPROVED BY	P.Punti	14/03/2023	



7.3 L92 PNEUMATIC LOCK



L92 PNEUMATIC LOCK

- Failing to use telescopic compensators could cause malfunction or premature wear of the pneumatic locking system.

- For the L92 configuration, the use of telescopic compensators is recommended [\[See L92 PNEUMATIC LOCK: USE WITH COMPENSATORS page 29\]](#).

- If you decide to work without compensators, carefully read the following chapter their operation [\[See L92 PNEUMATIC LOCK: USE WITHOUT COMPENSATORS page 30\]](#).



INFORMATION


If the supply pressure drops below 4.5 bar the tool will not be activated.

7.3.1 L92 PNEUMATIC LOCK: USE WITH COMPENSATORS


The use of telescopic compensators allows screw-mounting or tightening in any position (V-Vertical, H-Horizontal, A-Angle) with the arm completely blocked.

For the use of compensators in your 3arm arm, follow these instructions.

1. Remove the guards and verify that the switches are in the locked position. Put them back immediately.




2. Install the compensator that you have acquired with the tool according to the needs of torque and size of the panel (*Consult your distributor regarding the characteristics of the compensators*).
3. Connect the tool along with your control device following the manufacturer's recommendations [[See ELECTROPNEUMATIC SYSTEM page 34](#)].
4. Compress the regulator into its position (V-Vertical, H-Horizontal or A- Angle) as necessary and actuate the tool.



7.3.2 L92 PNEUMATIC LOCK: USE WITHOUT COMPENSATORS

The configuration L92 allows different arm movements to be locked through the activation of the tool or, failing that, the electrovalve.




- 1- Rear cross radial lock
- 2- Middle cross radial lock
- 3- Front cross radial lock
- 4- Rear arm tilting lock
- 5- Front arm tilting lock

Below, the movements that are locked and unlocked depending on the position of the switch when the tool is operated. (The switches are on the cover of the arm).

Movements	Position of selectors	Cylinders blocked
All movements "free"	A	2, 4, 5
All the movements are locked	B	1, 2, 3, 4, 5
Vertical work. V Movements blocked except tilting of the rear arm	C	1, 2, 3, 5
Horizontal work. H The movements are locked, except the radial of the base	D	2, 3, 4, 5

If you decide to work with compensators, you should position the selectors of the cover in the blocking position (B). Place the MV432405 protectors at the base of each selector, after removing the existing covers. [See L92 PNEUMATIC LOCK: USE WITH COMPENSATORS page 29].

Depending on the Vertical (V) or Horizontal (H) work that is going to be carried out, you must position the switch as shown in the image.



If working in A (angle), the switches must be positioned at V (vertical) if a more vertical than horizontal position prevails, or otherwise H (horizontal).

In other words, taking 0° as a reference, the surface where the base of arm has been installed:

- $\leq 45^\circ \rightarrow H$
- $\geq 45^\circ \rightarrow V$


7.3.3 L92 PNEUMATIC LOCK: MANUAL ACTIVATION

When the wheel on the cover is operated (Versions L92), the arm's pneumatic lock is activated.

The wheel has to move from position 1 to 2.

To do this, apply a slight rotation, with your hand, as indicated in the diagram.

- 1- Wheel extended, arm free.
- 2- Retracted wheel, lock activated [[See L92 PNEUMATIC LOCK page 28](#)].




To disable the lock, proceed in reverse order (from 2 to 1), rotating it the opposite direction.

- Keep it in position 2 during maintenance tasks, periods when not in use, and when changing the tool and/or head.


-Manual actuation, together with the switches, enables you to lock the arm without the tool connected.

7.3.4 PNEUMATIC DIAGRAM L92



7.3.5 ELECTROPNEUMATIC SYSTEM

This system links the 3arm® L92 arm with the tool using a suitable controller or control device (DC) following the diagram below.



The left of the diagram represents the 3arm® arm while the right shows the tool that will be used, controlled by the control device (DC).

The connecting cables that you will find with the 3arm® arm are identified with the following correlation.

- a) Electrovalve. Cables labelled A (red and black cables).
The electrovalve is responsible for operating the arm locks when the tool is functioning.
- b) Parking. Cables labelled B (white and brown cables)
Provides a potential free signal when the arm is retracted. This signal can be used to enable other components such as a light, activate other processes, etc.
- c) Pressure switch Cables labelled C (green and yellow cables)
This component disables the tool when there is insufficient supply pressure (below 4.5 bar).

See further details on the connections between the control device (DC) and the distributor of the tool.

7.4 LIFTER / PNEUMATIC COLUMN

If you complement your 3Arm® equipment with a pneumatic lift or a lifting column, you can control the up and down movement from the control panel of your 3Arm® equipment and/or the control panel of the lift.


Press and hold the button until the appropriate position is reached:



-> Upward movement.




-> Downward movement.



CAUTION

- ✓ The pneumatic lifter should only be operated when the 3arm® equipment is not in use. (they cannot be used at the same time)
- ✓ During periods of inactivity the pneumatic lift should be positioned in its lowest possible position.

7.4.1 Lifter pneumatic diagram



8 MAINTENANCE

The arm does not require maintenance and, when used properly, anomalies are unlikely to occur. Even so, the main, simple repairs that you can do are set out.

8.1 COMPRESSED AIR MAINTENANCE UNIT

For good functioning of the compressed air unit, an air quality level of class 1.4.1 is recommended, according to the table attached. ISO8573-1 2010.

ISO 8573-1:2010 CLASS	PARTICLES				WATER		OIL
	Maximum number of particles of the following size [µm]/m ³ of compressed air			Mass Concentration	Vapour Pressure Dewpoint	Content of liquid	Total content (liquid, aerosol, gas)
	0.1 - 0.5 µm	0.5 - 1 µm	1 - 5 µm	[mg/m ³]	[°C]	[g/m ³]	[mg/m ³]
0	By definition of the user, less contamination than class 1						
1	≤ 20000	≤ 400	≤ 10	-	≤ -70	-	≤ 0.01
2	≤ 400000	≤ 6000	≤ 100	-	≤ -40	-	≤ 0.1
3	-	≤ 90000	≤ 1000	-	≤ -20	-	≤ 1
4	-	-	≤ 10000	-	≤ +3	-	≤ 5
5	-	-	≤ 100000	-	≤ +7	-	-
6	-	-	-	≤ 5	≤ +10	-	-
7	-	-	-	5 - 10	-	≤ 0.5	-
8	-	-	-	-	-	0.5 - 5	-
9	-	-	-	-	-	5 - 10	-
X	-	-	-	> 10	-	> 10	> 5

Periodically check the water level accumulated in the reservoir, and bleed if it has reached the limit.

8.2 PNEUMATIC LOCKING BRAKES

It is advisable to revise the functioning of the locking brakes periodically.

The frequency of this revision will, in each case, depend on the number of cycles carried out with them. It is recommended that correct operation is checked every 6 months. To check, adjust or replace them [See PNEUMATIC LOCKS page 44].

The stroke of the locking brake actuators is 1.2 mm.



CAUTION

Do not operate the pneumatic brakes at no load (with the sub-assemblies removed), as this would damage the mechanism.

8.3 TIGHTENING THE SCREWS

To ensure the equipment functions correctly, it is advisable to check the tightness of all the screws periodically. The recommended period is every 6 months. The recommended torque for the 8 screws of the arm is 40 Nm.

8.4 GENERAL CLEANING

It is advisable to carry out a general clean of the arm and accessories every week to keep the whole unit in good condition and prolong its useful life.

8.5 REPLACING THE GAS SPRING AND CYLINDER




BEFORE REPLACING THE GAS SPRING


- ✓ The equipment must be duly installed and integrated.
- ✓ Disconnect the pneumatic supply from the equipment.
- ✓ It is advisable to dedicate two operators to this task.
- ✓ If the arm has a double spring, in the event a fault is detected in one of the two, both springs must be replaced.

- 1- Adjust the arm to put it in the balanced position [see [BALANCED, CENTRED POSITION](#) page 21].
- 2- Remove the screws (2) (2.5 mm Allen key) and remove the cover (3).
- 3- Swivel the arm to its highest position.

WARNING! KEEP THE ARM IN THAT POSITION

- 4- Rotate the regulation flywheel (4) anticlockwise all the way.
- 5- Remove the screw (5) (3 mm Allen key) from the end of the fork.
- 6- Turn the regulation flywheel (4) again until the lower shaft of the spring protrudes.
- 7- Remove the lower shaft of the spring (6) in the direction indicated in the image, securing the spring (8).
- 8- Remove the upper shaft of the spring (7) and remove the spring (8) by moving it in the direction indicated.
- 9- Replace the spring (8) and proceed in reverse order for assembly.





Pay special attention to the position of the shock absorber within the groove of the arm shaft. If the shock absorber is single, mount it in the groove indicated with the notch (1), however, if the shock absorber is double, mount it in the grooves not marked with the notch (1). In turn, mount the "concave" face of the shock absorber facing downward.




ARMS WITH DOUBLE SPRING.

If the arm has a double spring, in the event a fault is detected in one of the two, both springs must be replaced.

8.6 ADJUSTING THE SPRING REGULATION SYSTEM

Operation to be carried out as maintenance, in case play should appear in the regulation assembly.

1. Move the arm to its lowest position.
2. Loosen the studs (1) (2.5 mm Allen key).
3. Adjust the nut (2) until there is no play. The noise must disappear. Do not tighten this nut too much, as it stops the regulation turning gently.
4. Re-tighten the studs (1) (2.5mm Allen key).




8.7 REPLACING THE HEAD



BEFORE REPLACING THE HEAD

- ✓ The equipment must be duly installed and integrated.
- ✓ Disconnect the pneumatic supply from the equipment (if connected).
- ✓ It is advisable to dedicate two operators to this task.

1. Remove all tension from the shock absorber (1) [See [BALANCING THE ARM](#) page 20].
2. Swivel the arm to its lowest position.
3. Remove the screws (2) (4 mm Allen key) and remove the cover (3).
4. Remove the stud (4) (3mm Allen key) and use an M6 extractor to remove the pin (5).
5. Swivel the arm to its highest position.
6. Remove the caps (6) and the screws (7) from the arm (6 mm Allen key).
7. The head (8) will be free and can be replaced by a new one. Proceed in reverse order for assembly.



8.8 REPLACING RADIAL PADS L11




BEFORE THE REPLACEMENT

- ✓ The equipment must be duly installed and integrated.

Operation valid for manual locking of the base and cross.

- 1- Loosen the handle (1) and remove it.
- 2- Loosen the stud (2) (1.5mm Allen key), untwist the cover (3) and take out the pusher (4).
- 3- Remove the safety ring (5) and use an M4 extractor to remove the pins (6).
- 4- Remove the cylindrical pusher (7).
- 5- Remove the screw (8) (7 mm Allen key) and use an M10 extractor to take out the brake assembly with the pads (9) and remove the brake disc (13).
- 6- Replace the brake assembly (9) and the brake disc (10) and screw them onto the shaft of the base with the screw (8) (7 mm Allen key).
- 7- Proceed in reverse order for assembly.




8.9 REPLACING TILTING PADS L11



BEFORE THE REPLACEMENT

- ✓ The equipment must be duly installed and integrated.

5. Loosen the studs (1) (2.5 mm Allen key) from the bottom of the arm.
6. Unscrew the brake assembly (2) with a compass wrench.
7. Remove the screw (3) (4 mm Allen key) from the brake assembly (2).
8. Replace the pad (4) with the new one. Apply sealant, tighten screw (3) (4 mm Allen key) and loosen it ¼ turn.
9. Screw in the brake assembly (2) and tighten the studs (1) (2.5 mm Allen key).



8.10 MAINTENANCE TABLE

The following table summarises the preventive maintenance tasks that will ensure the proper functioning of the equipment.

The time period detailed in the table corresponds to a normal environment. If your equipment is installed in a dirty environment (foundries, outside, dust, humidity...) you should reduce the interval between maintenance tasks.


DESCRIPTION ELEMENT	ACTION	PERIOD
Regulator filter (air group)	Look for breaks, scratches or any deterioration of the transparent resin vessel on the air filter, regulator.	Every six months
	Replace the filter cartridge.	Every two years or when the pressure drop is 0.1 MPa, whichever comes first.
	Remove moisture before it reaches maximum capacity. Manually open and close the air filter bleed tap. Using tools can damage the product.	Every six months
Screws and fasteners	Check tightening and functionality of the securing elements.	Every six months
General cleaning	When dirty, clean with a mild household product. Do not use other cleaning agents, as they may cause damage.	Monthly
General check of the pneumatic circuit and pneumatic connections	Carry out a general check of the fixings and housings between tubes. Check there is no air leakage and that the connectors are working correctly.	Monthly
Locking brakes	It is advisable to revise the functioning of the locking brakes periodically. The frequency of this revision will, in each case, depend on the number of cycles carried out with them. To check, adjust or replace them [See PNEUMATIC LOCKS page 44] .	Every six months
Regulation assembly	Clean and grease the threaded rod	Every six months

9 PNEUMATIC LOCKS

In case of malfunction of the pneumatic locks of your 3arm® arm
In versions L22 and L92, follow these checkpoints.

Supplement this information with that shown in section [\[See L22 PNEUMATIC LOCK page 25 and L92 PNEUMATIC LOCK page 28\]](#).

9.1 PNEUMATIC LOCKS: IDENTIFICATION



- 1- Rear cross radial lock
- 2- Middle cross radial lock
- 3- Front cross radial lock
- 4- Rear arm tilting lock
- 5- Front arm tilting lock

9.2 CHECK CONNECTIONS: DEVICE CONTROL – 3arm®

For L92 versions only.

The locks failing to act in versions L92 is often due to a bad connection between the device control and the 3arm®. To avoid this, it is advisable to activate the pneumatic lock manually. [\[See L92 PNEUMATIC LOCK: MANUAL ACTIVATION page 32\]](#).

If the check is satisfactory, so that the cylinders are operated manually, make sure that the 3arm® arm - tool controller connection is properly made [\[See ELECTROPNEUMATIC SYSTEM page 34\]](#). Also verify that the checkpoints described below are passed successfully.


9.3 CHECKING THE AIR SUPPLY

Operative valid for any locking cylinder.

To perform this check:

1. Release the air pressure of the arm.
2. Remove the cap (2), first removing the screws (1) (*2 mm Allen key*) and disconnect the air supply tube from the joint (3) that feeds the cylinder.
3. Allow the air to pass and activate the lock in question, checking that air flows through the tube.
4. Proceed in reverse order for assembly and verify the functioning of the lock again.


If the check is not satisfactory, review the pneumatic diagram paying special attention to the connection between tubes and derivations, pinching or a failure with the electrovalve (in versions L92).



9.4 CHECK CYLINDER ADJUSTMENT

Operative valid for any locking cylinder.

1. Release the air pressure of the arm.
2. Remove the cap (2), first removing the screws (1) (2 mm Allen key) and disconnect the air supply tube from the joint (3) that feeds the cylinder.
3. Loosen the stud (4) (2 mm Allen key).
4. Screw the cylinder (5) clockwise until it stops.
5. Slightly unscrew the cylinder (5) anticlockwise (approx. 1/12 turn).
6. Proceed in reverse order for assembly and verify the functioning of the lock again.



If the problem persists, it is probably due to a fault in the functioning of the cylinder (it must be replaced), or wear of the pads (they must be replaced).

9.5 REPLACING THE CYLINDER AND/OR RADIAL PADS



PRIOR TO REPLACING THE CYLINDER AND/OR RADIAL PADS


- ✓ The equipment must be duly installed and integrated.
- ✓ Disconnect the pneumatic supply from the equipment.

Procedure valid for the cylinders of the base and joint.

If you wish to replace the locking cylinder (9) carry out steps 1- 6 and 10-16.

If you have the pad replacement kit (12) carry out the full process.

1. Release the air pressure of the arm.
2. Remove the cap (2), first removing the screws (1) (2 mm Allen key) and disconnect the air supply tube from the joint (3) that feeds the cylinder.
3. Loosen the stud (4) (2 mm Allen key).
4. Remove the safety ring (5) and use an M4 extractor to remove the pins (6).
5. Unscrew the cylinder assembly (7) and remove it.
6. Remove the screws (8) (2 mm Allen key) and separate the cylinder (9) from the pushrod (10).
7. Remove the screw (11) (7 mm Allen key) and use an M10 extractor to take out the brake assembly with the pads (12) and remove the brake disc (13).



8. Replace the brake assembly (12) and the brake disc (13) and screw them onto the shaft of the base with the screw (11) (7 mm Allen key).
9. Replacing the pushrod (10).
10. Assemble the cylinder (9) and the pushrod (10) with the screws (8) (2 mm Allen key).
11. Position the cylinder assembly (7) and screw it on clockwise until the pushrod holes coincide (10) with the elongated holes of the lug.
12. Fit the pins (6).
13. Screw the cylinder assembly (7) all the way on and unscrew it slightly, anticlockwise (approx 1/12 turn).
14. Tighten the stud (4), fit the safety ring (5) and connect the supply pipe.
15. Put the cover in place (2) with the screws (1) (2 mm Allen key).
16. Check the lock works correctly.











 INFORMATION









The cylinder replacement kit MV405504 includes part (9).







The base pads replacement kit MV4062A4 includes part (12).

The joint pads replacement kit MV4064A4 includes part (12).






10 SPARE PARTS







CODE	DESCRIPTION	PICTURE
MV400104R	BASE WITHOUT LOCKING L00	
MV402503	BASE WITH LOCKING L11 - L22	
MV308403	BASE SPINDLE WITHOUT LOCKING L00	
MV402203	BASE SPINDLE - WITH L11 - L22	
MV400603	TILTING ARM DS - L00	
MV402103	TILTING ARM DS - L11-L22-L92	
MV3062A3	TILTING ARM DM - L00	
MV30H705R	TILTING ARM DM - L11-L22-L92	
MV495205R	CROSS UNIT -CENTRAL-	
MV306303	BASE & CROSS COVER	
MV403903	CROSS COVER	



MV308203	HEADMEMBER COVER	
40100603	SPINDLE CROSS UNIT -CENTRAL - NO LOCKING-	
MV403203	AXE OF THE CROSS UNIT - WITH MANUAL LOCKING-	
MV403203	AXE OF THE CROSS UNIT -CENTRAL - WITH PNEUMATIC LOCKING-	
MV308403	AXE OF THE CROSS UNIT -2ND TILTING ARM- NO LOCKING-	
MV3031A3	AXE OF THE CROSS UNIT -2ND TILTING ARM- WITH MANUAL BRAKE-	
MV3031B3	AXE OF THE CROSS UNIT -2ND TILTING ARM - WITH PNEUMATIC LOCKING -	
MV400504	TILTING ARMS' UNION	
MV498804R	STAY 500 (DM)	
MV494404R	STAY BRAZO 380 (DS)	
MV30C704R	FORK REGULATION ASSEMBLY Ø15	
MV30C704HR	FORK REGULATION ASSEMBLY Ø15 - HARD	

AC020056	REGULATING HANDWHEEL	
MV498904R	HEADS & CROSS UNIT AXIS WITH SCREWS	
MV31J603R	LOCKING HANDLE -UNION AXIS-	
MV432105	SWING ARM PAD REPLACEMENT KIT, 380 (DS)	
MV301003	DAMPER AXIS AT THE ARM	
MVFXXX04R ⁴	DAMPER KIT, 1 UNIT - DS	
MVHXXX04R ⁵	DAMPER KIT, 1 UNIT – DM (Max. 130 kg)	
MVHXXX04R ⁴	DAMPER KIT, 2 UNIT – DM (140- 260 kg)	
MV305205R	SWIVEL ARM LOCKING SUPPORT (L11, L22, L92)	
MV30G1A3	BUTTON PANEL COVER L22	
MV4075A3	BUTTON PANEL COVER L92	
MV404604R	SOLENOID VALVE PUNCH ASSEMBLY	

⁵ XXX corresponde a la carga del amortiguador

NH121136	SWITCH VM1000 4NU 08	
EL101500	PRESSURE SWITCH 1/8" NC 6 BAR	
NH026026	SMC SOLENOID VALVE	
MV431405	PARKING REPLACEMENT KIT	
MV406503	CLAO CAP CYLINDER 38	
MV405903	CLAO CAP CYLINDER 42	
MV405504	RADIAL ARM LOCK CYLINDER	
MV406004	SWING ARM LOCK CYLINDER	
MV499104R	AIR FILTER ASSEMBLY	
MV4062A4	D33 RADIAL PAD ASSY (From S/N: 003-631/ 004-95)	
MV4064A4	D33 JOINT/UNION PAD ASSY (From S/N: 003-631/ 004-95)	
MV4315A5	RADIAL ARM PAD REPLACEMENT KIT (Previous S/N: 003-631 /004-95)	

MV4316A5	JOIN PAD REPLACEMENT KIT (Previous S/N: 003-631 /004-95)	
MV431805	SWING ARM PAD REPLACEMENT KIT L22-L92	
MV431905	SWING ARM PAD REPLACEMENT KIT L11 (DM)	
MV432405	KIT CAP HOLDERS SELECTORS	
MV431105	MAGNET REPLACEMENT KIT	
MV431705	MAGNETIC BASE ANCHOR REPLACEMENT KIT	
MV432205	MAGNETIC BASE ANCHOR REPLACEMENT KIT, LOCK	
CM166400	RADIAL HANDLE L11	
M4202300R	TILTING LOCK HANDLE L11 - DS	
M31794A0R	TILTING LOCK HANDLE ASSEMBLY L11	
CM165100	BASE & UNION LOCK HANDLE L11 - HARD	
M31025A0R	TILTING LOCK HANDLE L11 - HARD	

MV3034A5R	MANUAL LOCKING DS - DM FRONT - L11	
M3210400R	MANUAL LOCKING DS - DM REAR - L11	
MV328104	FLOATING SPINDLE T2140801/00 3/4" (Stroke: 45 mm/ 1.77" – Torque max.: 300Nm – □: 3/4" – Weigh: 1.5Kg / 0.7lbs)	
MV328204	FLOATING SPINDLE T2141212/00 1/2" (Stroke: 40 mm/ 1.57" – Torque max.: 150 Nm – □: 1/2" – Weigh: 0.9 Kg / 0.4lbs)	

11 ACCESSORIES

Caution: not all the accessories shown below are compatible. Check the compatibility table [See COMPATIBILITY OF ACCESSORIES page 60].

BENCHES

(1) (2) (3)



Four wheels (two with brake)
Slots for fastening parts or tools.
Supports for tap holder or tools.

CODE	DESCRIPTION	DIMENSIONS		MAX. LOAD
TP0001A0	Small bench (1)	500 x 500 x 900 mm	19 11/16" x 19 11/16" x 35 7/16"	100 kg
TF0001A0	Medium bench (2)	850 x 850 x 850 mm	33 7/16" x 33 7/16" x 33 7/16"	200 kg
907B00A0	Large bench (3)	1100 x 850 x 850 mm	43 5/16" x 33 7/16" x 33 7/16"	500 kg

SUPPORTS



(1)



(2)

Tie for securing the machine
Magnetic support for placing it on a metal surface and securing the machine

CODE	DESCRIPTION	DIMENSIONS
BR000100	Small tie (1)	N/A
BR100100	Large tie (2)	N/A
IA000100	Magnetic support (3)	150x150
IB000100	Magnetic support (4)	Ø200
IC000100	Magnetic support (5)	Ø250





(3)



(4)(5)

TROLLEY



To move the work unit.
It has four orientable wheels.

DESCRIPTION	DIMENSIONS	
Carriage 700	700 x 700 mm	27 9/16" x 27 9/16"
Carriage 900	900 x 900 mm	35 7/16" x 35 7/16"
Electric carriage	900 x 900 mm	35 7/16" x 35 7/16"
Electric carriage	800 x 800 mm	31 1/2" x 31 1/2"

FIXED COLUMN

To secure to the floor using four metal studs.



DESCRIPTION/DIMENSIONS	
Column 62 mm	2 ½"
Column 112 mm	4 3/8"
Column 162 mm	6 3/8"
Column 275 mm	10 7/8"
Column 375 mm	14 ¾"
Column 450 mm	17 ¾"
Column 635 mm	25"
Column 740 mm	29 1/8"
Column 850 mm	33 ½"
Column 1100 mm	43 ¼"
Column 1350 mm	53 1/8"
Column 1600 mm	63"

LIFTER



It consists of a telescopic column and a pneumatic cylinder with anti-rotation.

DESCRIPTION	VERTICAL TRAVEL
Lifter 300	300 mm – 11 7/8"
Lifter 500	500 mm – 19 7/8"
Lifter 750	750 mm – 29 17/32"

COLUMN D63



Pneumatic lift. The vertical position can be locked at any point, it has a pneumatic cylinder. It can be secured to the ground, on a trolley or on the ground rail to have movement on two shafts.

DESCRIPTION	VERTICAL TRAVEL
Column 1500 D63	940 mm – 37"
Column 2000 D63	1440 mm – 56 11/16"
Column 2500 D63	1940 mm – 76 3/8"

EXTENSION

(1) (2)




Extender that enables the arm's working area to be increased. It can also be installed on other accessories, such as column, lift, beam, etc.

DESCRIPTION	ADDITIONAL WORK AREA
Extension 500 (1)	500 mm – 19 11/16"
Extension 1000 (2)	1000 mm – 39 3/8"



FLOOR RAIL



Rail to fasten to the floor and on which the different columns and lifts can be fastened. Several sections can be joined from a base section 2 m. The horizontal position can be locked at any point.

CODE	DESCRIPTION	TRAVEL
CL040000	Floor rail	1520 mm – 59 13/16"


LINEAR GUIDE



Guide for the horizontal movement of the arm. Several sections can be joined from a base section 2 m. This may be bench-top, fixed to the wall or ceiling, or on pillars of various heights that can be selected. The horizontal position can be locked at any point.

CODE	DESCRIPTION	TRAVEL
CL023300	Linear guide 1000	635 mm – 25"
CL020000	Linear guide 2000	1635 mm – 64 3/8"
CL023000	Linear guide 3000	2635 mm – 103 3/4"

ROTATION LIMITER



The rotation limiter is a flexible reinforced steel cable that limits the rotational movement of the front arm, to a maximum of 1 turn, with an added margin of 10% in each rotation direction.

To assemble it, unscrew the screws/studs (1) and (2) that come in the arm from the factory, and replace them with screws "A" and "B" in the KIT.

Screw "A" (M12) will go in position 1 and screw "B" (M10) in position 2.

CODE	DESCRIPTION
LG100600	Rotation limiter assembly

BASE ROTATION LIMITER



Support that limits the rotation of the radial arm of the equipment. The stops can be moved to adjust the range of rotation.

CODE	DESCRIPTION
LG000104	Rotation Limiter

HAND RAIL BRACKET



Bracket which enables you to couple your equipment to existing components in the workplace such as handrails, structures, etc.

CODE	DESCRIPTION
CL108500	Hand rail bracket

11.1 COMPATIBILITY OF ACCESSORIES

ACCESSORY	SERIES – 3 ARM					
	S0	S1	S2	S3	S4	S6
RADIAL EXTENSION	●	●	●	●	●	●
TROLLEY + FIXED COLUMN	●	●	●	●	●	●
FIXED COLUMN	●	●	●	●	●	●
PNEUMATIC TELESCOPIC LIFT	●	●	●	●	●	●
D63 PNEUMATIC LIFTER	●	●	●	●	●	●
FLOOR RAIL	●	●	●	●	●	●
LINEAR GUIDE	●	●	●	*	*	*
SMALL BENCH (500)	*	●	●	⊘	⊘	⊘
MEDIUM BENCH (850 x 850)	●	●	●	*	*	*
LARGE BENCH (1100 x 850)	●	●	●	●	●	●
SMALL TIE	⊘	●	●	*	⊘	⊘
LARGE TIE	●	●	●	●	●	●
HAND RAIL BRACKET	●	●	●	●	●	●
MAGNETIC SUPPORT	*	*	*	*	*	*
ROTATION LIMITER	⊘	⊘	⊘	●	⊘	⊘
BASE ROTATION LIMITER	●	●	●	●	●	●

- = Compatible
- ⊘ = NOT Compatible
- * = Please ask

12 WARRANTY

See attached guarantee document.

13 GUIDELINES FOR PACKAGING, TRANSPORT AND DISMANTLING

13.1 PACKAGING

Follow the instructions below for packing the equipment for location changes or shipments for repair and maintenance.

13.1.1 Preparatory measures

The equipment must be put out of service. Assembling the "transport safety elements" will prevent movement during transport and thus possible damage to the installation.

13.1.2 Choice of packaging

For long transport distances, the components of the production installation must be packed in such a way that they are protected from atmospheric conditions.

13.1.3 Inscription on the packaging

Observe the specific provisions of the country in which the equipment is transported. In fully closed packaging, an indication must be placed on the packaging indicating where the top is.

13.1.4 Packaging procedure

Place the components of the machine on manufactured wooden pallets. Use lashing straps to ensure the components are secured against possible falls. Attach all the technical documentation that must accompany the machine.

13.2 TRANSPORT

The following data must be taken into account for transport.

- ✓ External dimensions (width x depth x height), approx: 1160 x 570 x 360 mm
- ✓ Total weight depending on the segment: maximum approx. 23 kg

13.3 DISASSEMBLY

- ✓ The equipment must be taken out of service by duly trained and authorised personnel.
- ✓ The machine must be dismantled taking the safety instructions, waste disposal and recycling into account.
- ✓ Protect the environment. The machine must be disposed of pursuant to current regulations and guidelines on safety, noise prevention, environmental protection and accident prevention.

CE STATEMENT OF COMPLIANCE

The manufacturer:

Company: TECNOSPIRO MACHINE TOOL, S.L.U.
Address: P.I. Pla dels Vinyats I, s/n nau 1
City: Sant Joan de Vilatorrada
Country: Spain - EU

Declares that this product:

Name: Series 3
Serial number: From 004 - 468

It is classified as a machine according to the Machinery Directive 2006/42/EC and to which this Declaration refers, and complies with the following European EC Directives, and their applicable Essential Health and Safety Requirements (EHSR):

2006/42/EC – Machinery Directive

2014/68/EU – Pressure Equipment Directive

Authorised for documentation:

Mr Ramon Jou Parrot of TECNOSPIRO MACHINE TOOL, S.L.U.

TECNOSPIRO
MACHINE TOOL SL



Sant Joan de Vilatorrada, Tuesday, 31 October 2023

Ramon Jou Parrot, Technical Director

3arm[®]

TECNOSPIRO
MACHINE TOOL SLU